

enviroscape® installation instructions

INSTALLATION GUIDELINES:

It is best to contact a professional paper hanger to perform proper installation for easy up and easy down wall covering or mural. A qualified installer can be found here: http://www.ngpp.org/find_paperhanger.php

Environment:

Room temperature should be above 65° F (18°C) for 48 hours prior to install.
EnviroScape® should be acclimated to the same temperature as installation point for 48 hours prior to install.
Walls should not contain in excess of 5% residual moisture.

SURFACE PREPARATION:

Hanging surface must be smooth, undamaged, and free of dirt and moisture.

New Construction:

Use a white wall covering primer to conceal joints.
Roman: PRO-977 ULTRA-PRIME® Premium Pigmented Primer or similar is recommended.

Existing Construction:

Thoroughly clean surface of all dirt, grease, and anything that might adversely effect proper installation.
Properly prime surface with suitable product.
For painted drywall, Roman: PRO-909 VINYL PREP® Clear Wallpaper Primer or similar is recommended.
When hanging on other surfaces use proper primer for the surface to be applied.

PROCESS:

Spray water to back of the sheet until thoroughly saturated, or place in a dip tray.
Gently fold the sheet with adhesive parts facing each other to keep moist and allow adhesive to activate.
Set aside for 3 minutes.
Unfold sheet and place onto a wall from top to bottom.
Carefully smooth out bubbles and creases using a broad smoothing brush, not a squeegee, from the middle of the sheet out.
If necessary, re-spray with water around the edges during the entire process.
Allow surface to dry to the touch and wipe off any excess adhesive using a damp cloth or sponge.
Trim the excess waste using a straight knife with a fresh blade tip.

FINISHING:

When EnviroScape® or any wall covering is to be hung in a high traffic area it is recommended to finish either pre-hanging or post-hanging with a clear coating. When finishing post-hanging Inx Digital ClearFlex™ ME can be applied with a paint roller following the manufacturers directions. This will ensure long life and greatly improve harm from abrasion. For best results always be sure to make every new cut with a clean sharp blade.

REMOVAL TIPS:

Spray the surface of the mural with water, allowing the water-based adhesive to relax for easier removal. Start at the top of the image and remove a 6-8" section of the panel completely, and then continue to draw the product back on itself at a 180 degree angle until the image is completely removed.
In instances where the substrate appears to be very tightly bonded to the surface, spray more water. After moistening the surface, allow the mural to stand for 60-90 seconds and then return to peeling the mural back upon itself.
Use a wet cloth to remove any remaining adhesive from surface.

These instruction are to be used as a guide for a successful installation of FiberMark EnviroScape® Wall Covering Product. Because there are a multitude of varying factors that are present in wall surfaces, and environments application testing is required before using product in production. FiberMark will only warrant the product is manufactured to specification at the print service provider level. Any claims on manufacturing defect will be during print or finishing process.

