

RIGID BOARD

Handling Instructions

Media Storage

Store product in areas protected from extreme temperature and humidity. Do not store directly on floor for prolonged periods. Recommendation is to store on pallets, shelves or in cabinets. Keep product in original packaging, which includes stretch wrap, and do not open sealed packages until ready for use. Removing the stretch wrap eliminates the protective barrier and can result in absorption or loss of moisture potentially resulting in quality issues such as curl, waviness and tight edges.

Stacking

Place cartons carefully on top of one another to avoid crushing edges or causing other damage. Never stack pallets on top of one another without the plywood tops included in the original shipment packaging.

Temperature

The temperature of the room where the product is stored can impact performance; optimum storage temperature is 68 to 76 degrees F (20 to 25 C).

Humidity

Desired storage conditions are in areas with a relative humidity of 35% to 55%. Exposure to a prolonged increase in humidity can cause this or any print media to develop curl or waviness that may impact aesthetics and functionality. When a significant decrease in humidity occurs, the product can dry out resulting in similar issues.

Climate Conditioning

Prior to printing, place product in print area, remove all stretch wrap, and allow to acclimate for 24-48 hours. Do not remove banding until product has acclimated for 24-48 hours. If all product is not used, replace the carton top for storage and future conditioning.

Neenahpaper.com/wideformat

NEENAH

US & CANADA 800-558-5061

®Registered Trademark and ™ Trademarks of Neenah, Inc. 2023 All rights reserved. Printed in the U.S.A



The mark of res**p**onsible forestr**y**